

Tabla CNS 4-A

Sistemas de Vigilancia

**(Parte IV, Vol. II - FASID -
del ANP CAR/SAM -
Reunión RAN CAR/SAM/3)**

Table CNS 4A – Surveillance Systems*EXPLANATION OF THE TABLE**Column*

1	Name of State/Territory and location of the radar station
2	Air Traffic Services Unit served by the facility
3	PSR / Function – Primary Surveillance Radar / Function E – En-route area control centres T – Terminal
4	Coverage of Primary Surveillance Radar in nautical miles
5	PSR / Status Imp. – Primary Surveillance Radar / Status Implementation
6	SSR / MSSR / Function – Secondary Surveillance Radar / Monopulse Secondary Surveillance Radar / Function E – En-route area control centres T – Terminal
7	SSR / MSSR / Modes – Modes A, C & S
8	Coverage of secondary Surveillance Radar in nautical miles
9	SSR / MSSR / Status Impl – Secondary Surveillance Radar / Monopulse Secondary Surveillance Radar / Status Implementation
10	ADS / Type – Automatic Dependent Surveillance / Type
11	ADS / Status Impl. – Automatic Dependent Surveillance / Status Implementation
12	Remarks

Note:

The following codes are used in columns 5, 9, 11 & 12

- 5, 9 & 11 I – Implemented using conventional SSR
 I* – Implemented using Monopulse SSR
 NI – Not implemented
 I/P – (Implemented/Planned. Indicates the implemented radar system and enlargement and/or replacement of the radar system at short term (2 years)
 P – Planned using SSR
 P* – stands for future plan using Monopulse SSR
 NP – (Not planned) – Indicates that the State has no plans for radar implementation
 R – Recommended
- 12 * MSSR – Monopulse SSR
 < - Year – Planned commissioning year
 > - Year – Planned decommissioning year

*EXPLICACION DE LA TABLA**Columna*

1	Nombre del Estado/Territorio y localización de la estación radar
2	Unidad de Servicio de Tránsito Aéreo servida por la facilidad
3	PSR / Función – Radar Primario de Vigilancia / Función E – En-route area control centres T – Terminal
4	Cobertura del Radar Primario de Vigilancia in millas náuticas
5	PSR / Estado Imp – Radar Primario de Vigilancia / Estado Implementación
6	SSR / MSSR / Función – Radar Secundario de Vigilancia / Radar Secundario de Vigilancia Monopulso / Función E – En-route area control centres T – Terminal
7	SSR / MSSR / Modos – Modos A, C & S
8	Cobertura del Radar Secundario de Vigilancia en millas náuticas
9	SSR / MSSR / Estado Impl – Radar Secundario de Vigilancia / Radar Secundario de Vigilancia Monopulso / Estado Implementación
10	ADS / Tipo – Vigilancia Dependiente Automática / Tipo
11	ADS / Estado Imp – Vigilancia Dependiente Automática / Estado Implementación
12	Observaciones

Note:

Los códigos siguientes son usados en las columnas 5, 9, 11 & 12

5, 9 & 11	I – Implementado usando SSR convencional I* – Implementado usando SSR Monopulso NI – No implementado I/P – (Implementado/Planeado. Indica un sistema radar implementado y enlargement y/o reemplazamiento de un sistema radar a corto término (2 años) P – Planeado usando SSR Monopulso P* – stands for futuro plan usando SSR Monopulso NP – (No planeado) – Indica que el Estado no ha planeado la implementación del radar R – Recomendado
12	* MSSR –SSR Monopulso < - Año – Año planeado para ser implementado > - Año – Año planeado para ser desinstalado