


Slide #10 – detailed notes



1. Find Allocated and available 5LNC

- verify the existence of a code in the ICARD database
- Identify the state using the code **or** indicate its availability in a specific region.

To note: - *The information covers all ICAO regions*

- *transfer of codes is possible*

- *ICARD contains all codes created in the 1960s but also a certain amount of codes which were not coordinated with ICAO – these are flagged as « non-icao » codes*

2. Find 5LNC in Reserve List :

- enable the authorised user to search for a new 5LNC and post a request for allocation

3. Find Allocated 5LNC :

- find an information (allocation, geographical coordinates..)
- amendment can be requested by the coordinating country (update, deletion)

4. Check my request:

- The requests found in this menu are still pending – not yet approved by the ICAO data manager
- the authorised user can make all modification or withdraw the requests which are still pending for confirmation

5. Requests by block :

- Not recommended – will be withdrawn

6. Downloads - ICARD can generate

- List of codes by country
- List by name of codes
- List of duplicates per country
- List of duplicateds per code

7. List ICARD Contacts

- Provide information on counterparts in other states or regions

8. List Country code indicators

- List the ITU, ISO2, ISO3 country codes

9. Change password