

VIII. Logical Acknowledgement Message LAM

4. Purpose of the LAM Message

The LAM is the means by which the receipt and safeguarding of a transmitted message is indicated to the sending unit by the receiving unit.

The LAM processing provides the ATC staff at the transferring unit with the following:

- A warning when no acknowledgement has been received;
- An indication that the message being acknowledged has been received, processed successfully, found free of errors, stored and, where relevant, is available for presentation to the appropriate working position(s).

5. Message Contents

The LAM message shall contain the following items of data:

- Message Type;
- Message Number;
- Message Reference.

6. Example

- (LAMOMSJ/OMAE939OMAE/OMSJ718)