FASID Table ATS 3 - ASIA/PAC SSR Code Allotment

STATE or FIR

Code/Clave	BANGKOK	BRISBANE	BRUNEI	CHENNAI	COLOMBO	DHAKA	DELHI	FUKUOKA	HANOI	HO CHI MINH	HONG KONG, CHINA	INCHEON	JAKARTA	KABUL	KARACHI	KATHMANDU	KOLKATA	KOTA KINABALU	KUALA LUMPUR	LAHORE	MALE	MANILA	MELBOURNE	MUMBAI	NADI	NEW ZEALAND	PHNOM PENH	PORT MORESBY	PYONGYANG	SINGAPORE	TAHITI	UJUNG PANDANG	ULAN BATOR	VIENTIANE	YANGON	BEIJING	GUANGZHOU	KUNMING	LANZHOU	SHANGHAI	SHENYANG	TAIBEI	URUMQI	WUHAN
0000																																													
0001-0077																															D						I								
0100-0177																D				D											I										I				
0200-0277				D			D					D					D				D			D		I								D										
0300-0377		*14*										D							D			D		I				D					D									D		D
0400-0477		*14*						D									I	I										D					D											
0500-0577							I											D							I				D															
0600-0677				I																		D														D	D					D		
0700-0777	I																																							D				
1000-1077	D	I						D																																D		D	D	
1100-1177	D	I						D																															D		D	D		
1200-1277	D	I						D																																	I			
1300-1377	D							D															I																					
1400-1477	D							D															I																					
1500-1577								D															I																			D		D
1600-1677												D															I *1*						D		I *2*									
1700-1777								D	I				D																															
2001-2077								D										I		D																						D		
2100-2177								D											I																				D			D		
2200-2277								D																							I							D						
2300-2377								D					I																							D		D					D	
2400-2477								D					I																								D							
2500-2577								D					D			I																									D			
2600-2677																	D		I													I										I		
2700-2777				D																		I																		D				
3000-3077																			D																	I								
3100-3177								I *13*										D																			I							
3200-3277								I							D																													
3300-3377	D			D			D	D			I *15*		D				D							D																				
3400-3477								D							D				D						D											D	D							
3500-3577											I																																	
3600-3677								I												D																								
3700-3777								I																																				

FASID Table ATS 3 - ASIA/PAC SSR Code Allotment

STATE or FIR

Code/Clave	BANGKOK	BRISBANE	BRUNEI	CHENNAI	COLOMBO	DHAKA	DELHI	FUKUOKA	HANOI	HO CHI MINH	HONG KONG, CHINA	INCHEON	JAKARTA	KABUL	KARACHI	KATHMANDU	KOLKATA	KOTA KINABALU	KUALA LUMPUR	LAHORE	MALE	MANILA	MELBOURNE	MUMBAI	NADI	NEW ZEALAND	PHNOM PENH	PORT MORESBY	PYONGYANG	SINGAPORE	TAHITI	UJUNG PANDANG	ULAN BATOR	VIENTIANE	YANGON	BEIJING	GUANGZHOU	KUNMING	LANZHOU	SHANGHAI	SHENYANG	TAIBEI	URUMQI	WUHAN
4000-4077																				D			D							I																D
4100-4177						D			D			I																					I												
4200-4277	D											D											D								D			I											
4300-4377	D											I *12*			D																D												D		
4400-4477	D											I 12								D													D	D									D		
4500-4577	D											D								I													D					D					D	D	
4600-4677								D	D																						D		D										D		
4700-4777						I		D					D																																
5000-5077												D																D *3*					I			I*4* D								
5100-5177											I	D							D																										
5200-5277								D*11*			D	D						D																		I*5* D								
5300-5377								D			I			D																															
5400-5477								D											I																										
5500-5577								D		I																																			
5600-5677								D		I																							D												
5700-5777								D		D	I *16*																																		
6000-6077								I		D																																			
6100-6177	I							I *13*																																					
6200-6277								D					D																											I *6*			I	I *7*	I *8*
6300-6377							D																		D								D								I				
6400-6477								D					D																										I *9*			I *10*			
6500-6577																							I																						
6600-6677												D																					I												
6700-6777												D	I																																
7000-7077								I *13*	I																								I												
7100-7177												I	I	I																															
7200-7277	D											D	D		I																		D										D		
7300-7377			D		I			D																															D			D			
7400-7477					D							D			D						I								I																
7500																																													
7600																																													
7700																																													

I = International/internacional
D = Domestic/interieur/nacional
1 = Codes/claves 1600-1637
2 = Codes/claves 1640-1677
3 = Codes/claves 5010-5077
4 = Codes/claves 5000 international/5001-5007 domestic
5 = Codes/claves 5200 international/5201-5207 domestic
6 = Codes/claves 6200-6217
7 = Codes/claves 6220-6237
8 = Codes/claves 6240-6277
9 = Codes/claves 6400-6447
10 = Codes/claves 6450-6477
11 = Not available for use in the western part of the Fukuoka FIR
12 = Not for southbound flights
13 = For eastbound/northeast bound flights
14 = Not avialble for use in Northeastern Australia
15 = For flights bound for China and for destinations within the Manila and Taipei FIRs
16 = Not for flights bound for destinations within and overflying the Fukuoka FIR

* ALL CODES AVAILABLE FOR DOMESTIC USE IN AUSTRALIA AND NEW ZEALAND EXCEPT WHERE INDICATE